

| Vehicle type | Engine | Manual gear box | Capacity (cm ³) | Bore (mm) | Stroke (mm) | Ratio |
|--------------|--------|-----------------|-----------------------------|-----------|-------------|-------|
| X063 | C3G | JB1 | 1239 | 74 | 72 | 9,2 |

Engine repair manuals for reference : Fascicule MOT. C.

When removing the engine, the engine - gear box assembly must be removed.

| SPECIAL TOOLING REQUIRED | |
|--------------------------|----------------|
| Mot. 1014 | Pressure gauge |

CONSUMABLES


| | |
|---------------------------|---------------|
| Gas leak detector product | 77 11 143 071 |
|---------------------------|---------------|

Detecting external oil leaks is made easier by putting the oil in the engine under pressure and spraying a "gas leak detector product" onto the area where the leak is thought to be.

CONNECTION

On the oil vapour rebreathing circuit : (allows checking of the engine volume which is not under oil pressure).

Connection example :



Pressure gauge Mot. 1014 used with socket end (A) for connection to the oil vapour rebreathing circuit.

METHOD :

NEVER ALLOW THE PRESSURE TO EXCEED 80 MILLIBARS.

If this pressure is exceeded, the lip seals invert.

Unscrew the pressure gauge Mot. 1014 release valve screw completely before connection to the rebreathing circuit.

Increase the pressure slowly to 80 millibars and check :

- sealing at the filler plug and the dipstick,
- any air leaks in the air inlet circuit (rebreathing circuit not plugged).

Spray the leak detector product in large quantities over the suspected area and look for the formation of soapy bubbles.

NOTE :

In certain cases, surrounding components may have to be removed.

Example : engine flywheel protective plate.

This operation may also be carried out on the engine when it has been removed from the vehicle.

If this operation is carried out after a repair, wait for the sealing paste to harden, and test for a short period only to avoid pushing the sealing paste out.

CHECKING METHOD

An engine may consume 1 litre every 1 000 km (625 miles).

Check there is no external oil leak.

To ensure the test is accurate, certain conditions must be observed when draining the engine oil :

- the engine must be warm,
- the dipstick and filler plug must be removed.

Drain the oil from the engine, letting it drip out for at least 15 minutes.

Refit the drain plug and "seal" it (spot of paint covering the plug and sump) so that you can check at a later date whether the plug has been removed.

Use a measuring cylinder to check the amount of oil required to fill the engine.

C3G engine : 3 litres

Refit the filling plug and seal it.

Ask the driver to return the vehicle after completing 1 000 km (625 miles) having noted the oil level using the dipstick at regular intervals.

When the vehicle is returned, check the filling plug and drain plug have not been tampered with.


The same conditions must be observed as before:

- the engine must be warm,
- the dipstick and filler plug must be removed.

Drain the oil and use the measuring cylinder to check how much oil is collected.


Calculate the oil consumption in litres for 1 000 km if the distance covered is different.

| SPECIAL TOOLING REQUIRED | | |
|--------------------------|--------|----------------------|
| B. Vi. | 31 -01 | Roll pin punch |
| T.Av. | 476 | Ball joint extractor |
| Mot. | 1202 | Rubber collar clamp |


| TIGHTENING TORQUES (in daN.m) | |  |
|--|-----|---|
| Brake caliper mounting bolt | 10 | |
| Shock absorber base mounting bolt | 11 | |
| Track rod end | 3,5 | |
| Lower ball joint nut | 6,5 | |
| Driveshaft gaiter mounting bolt | 2,5 | |
| Wheel bolts | 9 | |
| Engine mounting to rear strut bolts | 9,5 | |
| Front rubber mountings to side members bolts | 6 | |

REMOVAL

- Put the vehicle on a 2 post lift
- Disconnect the battery.
- Remove the air filter assembly.




- Disconnect the absolute pressure sensor connector and pipe.




- Disconnect:
- the master vac pipe,
 - the oxygen sensor connector,
 - the clutch cable,
 - the accelerator cable,
 - the coil HT cable and connector,
 - the fuel pipes on the throttle body.

Disconnect the engine connector in the connection unit next to the battery.



- Remove:
- the two injection relays and use a small screwdriver to unclip and remove the relay plate,
 - the injection computer (3)

- Disconnect:
- the connector (2),
 - the two earth straps under the computer at (1).



- Remove:
- the front wheels,
 - the engine undertray.

Drain the gear box.


Release the gear selection control from the gear box side.

Remove the exhaust flange.

Disconnect the exhaust and attach it to the body with the gear selection control.

Drain the cooling circuit from the cylinder block screw, timing side.

- Remove:
- the heating hoses from the water pump,
 - the hose from the expansion bottle on the radiator,
 - the bumper and wing protectors.



Remove:

- the headlights,
- the front right hand side indicator repeater,
- the earth bolt.


Disconnect the wiring.

Remove the bonnet lock and disconnect the cable.


Left hand side

Remove:


- the front left hand brake caliper bolt (A) suspend the caliper from the body.



- the track rod end using extractor T. Av. 476,




- the three gaiter bolts,
- the shock absorber base bolts and the lower ball joint,
- the stub axle carrier and driveshaft assembly, protecting the spider.




Right hand side

Remove:

- the driveshaft roll pin using punches B.Vi. 31-01



- Remove:
- the front right hand brake caliper and suspend it from the body,
 - the upper bolt (1) and loosen bolt (2)




93 958 1 R1

Tilt the stub axle carrier and remove the driveshaft.


Disconnect the canister pipes
 (Mot. 1265)

- Remove:
- the radiator mountings at (B) and remove the radiator.



96 141 R

- the headlight support plate (C),




96 141 R1

At this stage in the removal operation, the engine - gear box assembly is resting on two points of rotation (engine and gear box mountings).


Attach a workshop crane with the load distributor.

Remove the rear gear box mounting at (A).




96 140 R

- Remove:
- the engine mountings at (E).



- the mountings at (F), gear box side



Remove the engine - gear box assembly

Remove support (A).

REFITTING - Special notes




We draw your attention to the importance of correct positioning of the engine - gear box assembly in the engine compartment.

Position the engine and gear box assembly in the engine compartment but do not compress the engine mountings.

Fit the bolt in the rear engine mounting.


Using tool Mot. 1272 position the engine - gear box assembly in relation to the guide hole in the left hand side of the rear engine mounting and the clutch housing guide hole.



FRONT RUBBER MOUNTING PADS

Support the engine - gear box assembly so that the upper surface (A) just touches the bottom of the side member

Ensure the engine is correctly centred in the front section by comparing the positions of sections (A) on the left and right hand side members



Torque tighten the rear mounting pad.

CHECKING

In order to check the engine and gear box assembly is correctly positioned, measure the two dimensions indicated with the engine no longer supported by the engine supports

If this measurement is not correct ($26 \text{ mm} \pm 1$), mark the actual position on the side member.

If the measurement is less than 25 mm, loosen the front support in question and push on section (A) to move it back. Retighten. Check the measurement again and repeat the operation if necessary.

If the measurement is over 27 mm, carry out the same operation, but move section (A) forwards.

Tighten the 4 bolts to the recommended torque ensuring that parts (A) are not moved during the tightening operation and that they remain parallel to the vertical face of the side member.

Fit the caliper mounting bolts using **Loctite FRENBLOC** and tighten them to the recommended torque.


Press the brake pedal several times to bring the pistons into contact with the brake pads.

Apply **CAF 4/60 THIXO** to the drive shaft roll pin holes.

Adjust the accelerator cable.

Fill:

- the gear box with oil,
- the cooling circuit with coolant and bleed the circuit (see section 19).



- 1 Front right hand engine mounting
- 2 Front left hand engine mounting

SPECIAL TOOLING REQUIRED


| | | |
|--------|--------|--------------------------|
| Elé. | 346-04 | Belt tension tester |
| Elé. | 346-05 | Belt tension testing bar |
| B. Vi. | 906 | Force measuring tool |

CALIBRATION OF TOOL Elé. 346

Two methods :


The calibration of tool Elé. 346 must be checked before it is used for the first time (new tool) and periodically thereafter.

1st method:



Apply a force of 3 daN (3 kg weight) to the tool. Shoulder (A) should touch the body of the spring section (B), otherwise turn screw (C) to increase or decrease the tool setting.

2nd method:




Fit tool Elé. 346 into a vice having remove the plug. Push the cylindrical section of the tool B. Vi. 906 against the sliding section. Shoulder (A) should touch the body of the spring section (B) when the needle indicates 3 daN, otherwise turn screw (C) to increase or decrease the tool setting.

CHECKING TENSION

C ENGINE FITTING


Flexing movement (F) : 2 ± 0.5

Check new belt after 10 minutes rotation.



- A Crankshaft pulley
- B Tensioner wheel
- C Water pump pulley
- D Alternator pulley

| SPECIAL TOOLING REQUIRED | | |
|--------------------------|--|---|
| Mot. 104 | | Pins for centring the gasket on the cylinder head |
| Mot. 521-01 | | Liner sleeve retainer and compression plate |
| Mot. 591-04 | | Angular wrench for tightening cylinder head bolts |
| Mot. 591-02 | | Magnetic pipe for head bolt angular wrench |
| Mot. 1 202 | | Collar pliers |

| TIGHTENING TORQUES (in daN.m) |  |
|-------------------------------|--|
| Cooling circuit drain plug | 1,2 |
| Tension wheel bolt | 4,2 |
| Tension wheel nut | 2 |

Disconnect the battery.

Remove:

- the air filter,
- the fuel pipes,
- the wiring on the throttle body,
- the alternator drive belt,
- the exhaust down pipe mountings,
- the distributor.

Drain the cooling circuit from the drain plug (1) in the cylinder block.



Remove:

- the upper radiator hose,
- the rocker box cover,
- the rocker push rods,
- the cylinder head bolts except for bolt (A).

The cylinder head centring pins located under the central bolt (A) on the timing side.

Leave this bolt until the cylinder head is to be removed


Remove the other bolts.



Since the cylinder head gasket is stuck to the cylinder head, the cylinder block and the liners, it is very important not to lift the cylinder head which would separate the liners from their bases and lead to the ingress of foreign bodies.

The cylinder head must be rotated around the centring pin (cylinder head mounting bolt left in place) to release the gasket from the cylinder block.


Release the cylinder block by tapping the ends with a hammer in a horizontal rotation direction.



Remove the mounting bolt (A).

Remove the cylinder head.

Fit the liner retaining tool **Mot. 521-01**



CLEANING


It is very important not to scratch the sealing surfaces of parts in aluminium.

Use a Décap joint seal removing product to dissolve any part of the seal which is still stuck to the metal

Apply the product to the areas to be cleaned: wait for approximately 10 minutes then remove the waste with a wooden spatula.

REFITTING

Fit the cylinder head centring pins **Mat. 104** at (B)



Refit the cylinder head.

METHOD FOR TIGHTENING THE CYLINDER HEAD

This operation should be done when the engine is cold, after replacing the cylinder head, and should not be carried out later.

Reminder:


In order to ensure the bolts are tightened correctly, remove any oil in the cylinder head mounting holes using a syringe

Use engine oil to grease the threads and under the heads of the mounting bolts.

Tighten in the recommended order :

1st tightening : 2 daN.m

Wait 3 minutes minimum, to allow the gasket to settle.



81 528-15

Final tightening:

- 1) loosen the bolt marked 1 (all the other bolts remain tight),
- 2) torque tighten the bolt marked 1 to 2 daN.m \pm 0,3 (all the other bolts remain tight)
- 3) Angle tighten the bolt to 90° \pm 4° (all the other bolts remain tight)

PROCEED IN THE SAME MANNER FOR THE REMAINING BOLTS MARKED 2 TO 10, IN ASCENDING NUMERICAL ORDER.

Adjust the rockers (mm)

Inlet 0,15

Exhaust 0,20

Refitting is then the reverse of removal.

Fill and bleed the cooling circuit

MISTURA - CARBURAÇÃO Generalidades

12

CARACTERÍSTICAS E VALORES DE AFINAÇÃO

| Veículo | Motor | | | | | | Caixa de velocidades | Tipo de injeção |
|---------|-------|--------|---------------|------------|-------------------------------|-------|----------------------|---------------------------|
| | Tipo | Índice | Diâmetro (mm) | Curso (mm) | Cilindrada (cm ³) | Taxa | | |
| X 063 | C3G | 700 | 74 | 72 | 1239 | 9,2/1 | BM | Monoponto Magnéti Marelli |

| Motor | Controlo do ralenti | | Combustível | |
|----------|---------------------|------------------------------|---------------------|---------------------------|
| | Regime (rpm) | Riqueza (CO) | Particularidade | Índice de Octano (mínimo) |
| C 3G 700 | 700 ± 50* | VC: 0,3 máx. VL: 0,5 máx. | Gasolina sem chumbo | I.O. 91 |

* Para uma temperatura de água compreendida entre 80 e 100°C.

VC: valor de controlo


VL: valor legislativo

| | |
|---|--|
| Tipo de alimentação | Injeção monoponto regulada |
| Bomba de alimentação imersa, colocada no depósito Tipo: Jaeger | Tensão: 12 volts Pressão: 1,05 ± 0,05 bars Débito: 50 l/h mínimo |
| Filtro de gasolina fixo à frente do depósito, sob o veículo | Substituição todos os 50.000 km |
| Caixa de borboleta monoponto | SOLEX: Ø 32 mm |
| Regulador de pressão integrado na caixa de borboleta | Pressão: 1,05 ± 0,05 bars (sem afinação) |
| Injector electromagnético | Tensão: 12 volts Resistência: 1,8 Ω aproximadamente |
| Motor passo a passo de regulação de ralenti | Sem afinação. Controlo com XR25#12: 2 a 10% em regulação ralenti |
| Potenciómetro de posição da borboleta | Controlo com XR25#17 Em regulação de ralenti: 9 a 41 Borboleta aberta a fundo: 168 a 235 |


SPECIFICATIONS AND ADJUSTMENT VALUES

| Computer | Magneti Marelli N° | Homologation N° | R.N.U.R. N° |
|---------------------------------------|--------------------|-----------------|---------------|
| Magneti Marelli in engine compartment | 16085 - 024 | 77 00 856 784 | 77 00 864 461 |


| Temperature in °C | 0 ± 1 | 20 ± 1 | 40 ± 1 | 80 ± 1 | 90 ± 1 |
|---|---------------------|--------------------|--------------------|------------------|------------------|
| Air temperature sensor Type - CTN M Marelli Resistance in Ω | 8770 to 10720 | 3370 to 4120 | 1440 to 1760 | -- | -- |
| Coolant temperature sensor Type - CTN Siemens. Resistance in Ω | -- | 3060 to 4045 | 1315 to 1600 | 300 to 370 | 210 to 270 |

| | |
|--|--|
| AC Rochester oxygen sensor | at 370°C - Rich mixture : ≥ 800 mV - > Poor mixture : 0 to 200 mV |
| Catalytic converter (under floor) |  C26 |
| Paper cartridge air filter Thermostat control from 26 to 36 °C | Replacement : 20 000 km |
| E.G.R. | |
| Anti-evaporation system : Canister | CAN 13 |
| Ignition | Advance and power circuit integral in injection computer - Ignition coil - External advance correction |
| Plugs | BOSCH W9DC NGK BP5ES2 Gap: 0,9 ± 0,05 mm (adjustable) |

SYSTEM COMPONENTS




- A : Injector
- B : Idle speed regulation stepping motor
- C : Fuel pressure regulator
- D : Air temperature sensor
- E : Throttle position potentiometer
 - 1 : Signal output
 - 2 : Feed
 - 3 : Earth




- F : Fuel section - injector body
- G : Air section - throttle body
- H : Connections joining the two sections
- I : fuel inlet
- J : Fuel return
- K : Hot water circulation
- L : Hot water circulation
- M : Canister bleed

THROTTLE BODY REMOVAL - REFITTING

Remove:



- the air filter, undoing the two bolts (1) and clip (2).



Disconnect:

- the fuel supply pipes (3) and return pipes (4).
- the water pipes (5) and (6)
- the fuel vapour recirculation pipe (7)
- the accelerator control cable
- connectors A and B.
- connector C and the wire channel (8)
- the air temperature sensor connector (D) (the connector is identical to that for the injector)

Remove the two bolts (9) and remove the throttle body.


When refitting :

- check the riser joint between the throttle body and the inlet manifold is flat, replace it if necessary.
- reconnect the various pipes and ensure the connectors are correctly connected.

Note : the water pipe collar bolt (5) must be positioned at the bottom (see diagram) so the injector wiring is not damaged.

REMOVAL AND REFITTING OF VARIOUS COMPONENTS ON THE THROTTLE BODY.

INJECTOR REMOVAL - REFITTING



Completely remove the air filter.
Disconnect the injector connector.
Remove bolt (1) and mounting bracket (2).
Remove the injector from its position.
Check that the small diameter O ring is retained, from the lower section of the injector position and check the sealing face of the seals (use a mirror)


When refitting :

Replace the O rings and lubricate them (silicon free lubricant).
Ensure bolt (1) is correctly tightened and the connector is correctly fastened.

Note : When the injector is replaced, the new component is supplied with new O rings.

IMPORTANT : Never connect the injector directly to a 12V source as it may be damaged.

**IDLE SPEED REGULATION STEPPING MOTOR
REMOVAL - REFITTING**



Completely remove the air filter.
Disconnect the idle speed regulation stepping motor connector.
Remove the two motor mounting bolts (1) and remove the motor

When refitting:

Replace the O ring and lubricate it.
Ensure the connector is correctly refitted.

Note : When replacing the stepping motor, the new component is supplied with new O rings and mounting bolts.


Important :

Before starting the engine when the stepping motor has just been replaced turn the ignition on and enter code GO** on the XR25 to cancel the old values for the previous stepping motor

Turn the ignition off and the motor should position itself ready for the next time the engine is started.

Start the engine and check the operation of the idle speed regulation stepping motor using code #12.

**THROTTLE POSITION POTENTIOMETER REMOVAL
- REFITTING**



Remove the air filter.
Disconnect the throttle position potentiometer connector.
Remove the two potentiometer mounting bolts (1) and remove the potentiometer.

When refitting:


Check the potentiometer connector is correctly positioned and reconnected.

Note: This potentiometer cannot be adjusted.
New bolts are supplied with a new component

Note : After replacing the throttle position potentiometer turn the ignition on and check the operation of the potentiometer using code #17 on the XR25, and also check that the no load and full load positions are recognised.

Erase the memory using GO**

**AIR TEMPERATURE SENSOR REMOVAL -
REFITTING**




Remove the throttle body completely
Separate the air and fuel sections (tighten pins (2)
using thin nosed pliers).
Remove the two sensor mounting bolts and
remove the sensor

When refitting:

Visually check the riser joint and the two seals
between the two sections of the throttle body.
Replace them if necessary
Check that the riser joint between the throttle
body and the inlet manifold is flat.
Connect the various pipe connections and ensure
all connectors are correctly connected

Note : After replacing the air temperature sensor
turn the ignition on and use the XR25 to enter
code GO** to erase the memory

MANIFOLD REMOVAL - REFITTING



Remove:

- the air filter
- the throttle body
- the two mounting nuts holding the deflector plate under the throttle body and remove the throttle body.
- the fuel pipe support bracket (nut on stud) (A).
- the vacuum pipes to the absolute pressure sensor (B) and the master vac (C)

Release the electrical connections and pipes which pass over the manifold towards the gear box (the ignition coil and engine coolant temperature sensor connectors must be disconnected).

Remove the hot air inlet cone (nuts on stud) (D))

Disconnect the oxygen sensor

Remove:

- the exhaust downpipe.
- the manifold mounting nuts (E) and remove the manifold.

When refitting:

Replace the manifold gasket and position the crimped side on the side of the cylinder block.

Check and replace if necessary :

- the riser joint between the throttle body and the manifold.
- the sealing ring on the exhaust downpipe
- the seal on the deflector plate (when this is replaced it is supplied with the plate).

Refitting is then the reverse of removal.

Ensure :

- the electrical wiring and pipes are correctly routed
- all connectors and collars are correctly refitted


REPLACEMENT

The fuel filter should be replaced every 50000 km (30 000miles).

SPECIAL TOOLING REQUIRED

Mot. 1265

Pliers



The fuel filter is located under the vehicle in front of the fuel tank. It is mounted to the body by a bracket.

Fuel will run out when the filter is removed, (do not clamp the pipes as this may damage them).

Disconnect pipes (1) using tool Mot. 1265. (see diagram opposite for how to position the tool on the pipe)

Remove bolt (2) and remove the fuel filter (3)


When refitting, ensure the fuel is flowing the right way through the filter (arrow marked on the filter body)

Reconnect the pipes by hand. (it is not necessary to use the pliers Mot. 1265)

Ensure the unions are correctly fastened (two O rings)

Note : The pipes (1) cannot be disconnected without using pliers Mot. 1265.


Positioning the clamp.




CHECKING THE SUPPLY PRESSURE AND FLOW FOR THE FUEL PUMP

SPECIAL TOOLING REQUIRED

| | |
|------------------------------|--------------------------------|
| Mot. 843 | 0-6 bar pressure gauge |
| Mot. 867 | -1 + 2 bar pressure gauge |
| Mot. 904 | T union for measuring pressure |
| 1 2000 ml measuring cylinder | |



Measurements may be made with the engine running at idle speed or stationary, by shunting terminals 3 and 5 (large wires) on the fuel pump relay (A).



Remove the air filter
Disconnect the fuel inlet pipe (B)
Fit the T union **Mot. 904** and connect it to the -1, + 2 bar pressure gauge **Mot 867**.
Disconnect the return pipe (C) and replace it with a length of hose leading into a 2000 ml measuring cylinder
Run the fuel pump for one minute, then measure the pressure and amount of fuel in the measuring cylinder :

Pressure : 1,05 ± 0,05 bars
Flow : 0,83 l/min minimum.

ATTENTION :

If the flow is low, check the pump feed voltage (drop in flow of 10% for a voltage drop of 1 volt).


Note :

The operation of the fuel pump safety valve can be checked. To do this use the 0-6bar pressure gauge **Mot. 843** in place of the gauge used beforehand. Run the fuel pump, clamp the return pipe (C) for a short moment, and the pressure should be between 2,5 and 4,7 bar

IMPORTANT :

Never smoke or bring heat sources into the working area when working on the fuel tank or fuel supply circuit.

REMOVAL - REFITTING OF THE PUMP - GAUGE ASSEMBLY



The pump - gauge assembly may be removed directly through the flap under the rear bench seat. To do this :

- Disconnect the battery
- Tip the seat forwards.
- Lift the carpet and remove the plug.

Disconnect:

- the connector (1).
- the fuel supply pipe (2) and the return pipe (3) using the special pliers **Mot. 1265** (see diagram opposite for how to position the pliers)

Remove:

- the mounting nut using tool **Mot. 1264**.
- the pump - gauge assembly.

When refitting :

- check the seal is in good condition or replace it.
- refit the seal on the fuel tank before refitting the assembly.
- position the pump - gauge assembly (see reference mark A)
- torque tighten to **6 daN.m max**


Note :

- Pliers **Mot. 1265** do not need to be used to reconnect the pipes
- Ensure the unions are correctly reconnected (two O rings)


IMPORTANT :

Fuel will run out when the pipes are disconnected - protect the surrounding area (residual pressure). The pipes cannot be disconnected without using pliers **Mot. 1265**.

Positioning the pliers Mot. 1265



REMOVAL - REFITTING OF THE PUMP



- 1 Mounting nut
- 2 Fuel gauge
- 3 Fuel pump
- 4 Seal
- A : + fuel pump
- B : - fuel pump
- C and D : fuel gauge info

Remove the pump - gauge assembly.
Loosen collar (5) and remove the fuel pipe.
Disconnect the pump feed wires (6) and (7).
Remove the mounting bracket (8).
Separate the pump from the gauge.

When refitting:

Check the condition of the seal (4), replace it if necessary.
Ensure the feed wires are correctly connected (polarity).
Replace collar (5) and ensure it is correctly tightened.

CHECKS TO BE CARRIED OUT BEFORE THE ANTI-POLLUTION TEST

Ensure:

- the ignition system is operating correctly (correct type plugs, correctly set, HI leads correctly connected and in good condition).
- the injection system is operating correctly (correct supply, check conformity with XR25)
- conformity and sealing of exhaust line

Obtain information of the vehicle's history if possible (run out of fuel, lack of power, use of incorrect fuel type)

ANTI-POLLUTION STANDARDS TEST

Let the vehicle warm up until the engine cooling fan has operated twice.

Connect a correctly calibrated four gas analyser to the exhaust pipe

Keep the engine speed at 2500 rpm for 30 seconds and read off the pollutant values.

CO \leq 0,3 %

CO₂ \geq 14,5 %

HC \leq 100 ppm

0,97 \leq λ \leq 1,03

Note : $\lambda = \frac{1}{\text{richness}}$

$\lambda > 1 \rightarrow$ poor mixture

$\lambda < 1 \rightarrow$ rich mixture

If these values are correct after the test, the anti-pollution system is operating correctly

otherwise additional test must be carried out

- check the condition of the engine (condition of the oil, valve clearances, timing, etc...)
- check the oxygen sensor is operating correctly (ch. 17).
- test for the presence of lead (see below)


If the test for lead is positive, wait until the vehicle has used two or three full tanks of unleaded fuel before replacing the oxygen sensor.

If, after all these test have been carried out, the values are still incorrect, replace the catalytic converter.

The Nauder lead testing kit is required for this test.

For further information, please contact your After Sales Head Office.

- Part numbers :
- Complete kit : T900
 - 40 test papers : T900/1




METHOD

Detecting lead at the exhaust

- a - Test conditions :
 - Engine stationary.
 - Exhaust pipes hot but not burning.
 - Do not test when the temperature is below 0°C.
- b - If necessary use a soft cloth to clean the inside of the exhaust pipe so any soot deposits are removed.
- c - Wearing the gloves, take a test paper and moisten it slightly with distilled water (the paper is not effective if it is too wet).
- d - Press the damp paper onto the cleaned exhaust pipe immediately and hold it there firmly for about a minute
- e - Remove the test paper and allow to dry. The test paper will turn red or pink if lead is present.

ATTENTION : The test for lead should only be carried out on the exhaust pipe, not on the oxygen sensor.

OPERATIONAL DIAGRAM




- 1 Air filter
- 2 Rocker box cover
- 3 Throttle body
- 4 Inlet manifold
- 5 $\varnothing 6,5$ mm nozzle upstream of throttle.
- 6 $\varnothing 1,3$ mm nozzle downstream of throttle

Testing:

To ensure the anti-pollution system operates correctly the vapour rebreathing circuit must be kept clean and in good condition. Check the nozzles are present and in good condition.

OPERATING PRINCIPLE



The fuel tank is vented through the fuel vapour absorber (or canister) (1) through pipe (3).

The active carbon in the canister retains the fuel vapours as they pass through.

Under certain engine operating conditions (engine speed, pressure temperature), the computer determines the cyclical opening ratio (RCO) for the canister bleed solenoid valve (2)


The solenoid valve allows the amount of fuel vapour recycled by the canister (via pipe (4)) and directed to the inlet manifold (via pipe (5)) to be varied

The variation in the section through which the fuel vapour passes is caused by the balance between the magnetic field created by feed to the coil and the force on the return spring which closes the valve.


Note :

When removing the canister use pliers **Mot. 1265** to disconnect pipe (3).

When reconnecting pipe (3) ensure the union is correctly connected (two O rings).



OPERATIONAL DIAGRAM OF THE CIRCUIT



- 1 Throttle body
- 2 Canister bleed control solenoid valve
- 3 Fuel vapour absorber (or canister)
- A Pipe from fuel tank for fuel vapour recycling
- B Vent.
- C Take-off upstream of throttle.

IDENTIFICATION


| VEHICLE | ENGINE | ALTERNATOR | CURRENT |
|---------|--------|----------------------------|---------|
| C063 | C3G | MAGNETI MARELLI CG33211.70 | 60 A |

CHECKING

After letting the engine warm up for 15 minutes at 13,5 Volts

| rpm | current |
|-------|---------|
| 1 500 | 10 A |
| 3 000 | 50 A |
| 6 000 | 60 A |

DIAGRAM



96 276 5

- 1 Ignition switch
- 2 3 W warning light bulb
- 3 Condenser
- 4 Voltage regulator
- 5 Brush

OPERATION - FAULT FINDING

This vehicle is fitted with an alternator with integral regulator. The warning light has the following functions:

- when the ignition is switched on, the light illuminates
- when the engine is started the light extinguishes,
- if the light illuminates while the engine is running, there is a charging fault.

LOOKING FOR FAULTS

The warning light does not illuminate when the ignition is switched on.

Check:

- all electrical connections are good.
- the bulb has not blown. (Earth terminal L (having disconnected it) ; the bulb should illuminate).

The warning light illuminates when the engine is running.

This indicates a charging fault which could be caused by :

- the alternator drive belt being broken or the charging wiring being cut,
- internal alternator deterioration (rotor, stator, diodes or brush),
- a regulator fault,
- excess voltage.

The customer complains of a lack of charge and the warning light is operating correctly.

If the regulated voltage is less than 13,5 V, check the alternator. The fault could be caused by :

- a diode which has been damaged,
- a phase which is cut,
- coked or worn tracks.

Checking the voltage

Connect a voltmeter across the battery terminals and read the battery voltage.

Start the engine and increase the engine speed until the needle registers a stable regulated voltage.

This voltage should be between 13,5 V and 14,8 V

Connect as many consumers as possible, the regulated voltage should be between 13,5 V and 14,8 V.


ATTENTION : *if arc welding work is to be carried out on the vehicle, the battery and regulator must be disconnected.*

REMOVAL - REFITTING

Do not use a screwdriver to remove the drive belt as it is made of synthetic fibres and may be damaged

Disconnect the battery

REMOVAL



Undo tensioner bolt (A) to slacken the belt.

Loosen the nut on the tensioner mounting (B) and release the belt.

Disconnect the electrical connections.

Remove the 3 alternator mountings (C) (2 nuts and 1 bolt).

Remove the alternator

REFITTING

Refitting is the reverse of removal. Ensure the drive belt is adjusted to the correct tension.

IDENTIFICATION


| VEHICLE | ENGINE | STARTER |
|---------|--------|--------------------|
| C063 | C3G | BOSCH 000 111 2025 |

REMOVAL - REFITTING

Vehicle on a lift, disconnect the battery.


Remove the engine undertray.

REMOVAL




From below the vehicle:

- remove the 2 mountings (A) for the starter protective plate (1 bolt and 1 nut),
- release the protective plate and remove it,
- disconnect the starter electrical connections,
- loosen the mounting bolt (B) for the starter retaining bracket at the rear of the starter, but leave the bolt in position.




From above :

- remove the air filter - 2 bolts (C) and one clip (D).



Remove the air filter only after disconnecting the oil vapour rebreathing pipe.

- Separate the pipes and wires to reach the three starter mounting bolts (E) and remove them



From above:

- reconnect the battery,
- try the starter,
- refit the air filter.

Replace the engine undertray.

From below the vehicle :

- remove mounting bolt (B) from the retaining bracket,
- remove the starter.

REFITTING

From below the vehicle :

- reposition the starter using bolt (B) in the starter retaining bracket.

From above:


- replace the 3 mounting bolts (E) and tighten them.

From below the vehicle :

- reconnect all connections,
- tighten bolt (B),
- refit the starter protective plate.


The ignition advance function and the ignition power circuit are integral to the injection computer which sends the control signal to the ignition coil.

LOCATION



Fault finding

The line between the ignition coil and the injection computer can be diagnosed using the XR25. (See fault finding with XR25.)




1 3

96 311 R

Connection


| Track | Allocation |
|-------|-----------------------|
| 1 | Not used |
| 2 | Feed via pump relay |
| 3 | Ignition coil control |



96 144 R

- | | |
|--|--|
| 1 : Throttle body | 2 : Absolute pressure sensor |
| A : Injector | 3 : Diagnostic socket |
| B : Air temperature sensor | 4 : Canister bleed solenoid |
| C : Throttle position potentiometer | 5 : Coolant temperature sensor |
| D : Idle speed regulation stepping motor | 6 : Injection computer (under plastic cover) |
| E : Fuel pressure regulator | 7 : Ignition coil |
| F : Fuel supply | |
| G : Fuel return | |

REMOVAL - REFITTING OF THE COMPUTER




The computer is located in the engine compartment near the battery. To remove the computer, it is not necessary to remove the plastic protective cover.

- Disconnect the battery
- Remove the wiring from the clip (1).
- Remove the two nuts (3) and release the computer (4). The computer is mounted by two clips at the bottom (5).
- Disconnect the connector (2).


When refitting, check the connector is correctly refitted (2).

LOCATION OF RELAYS



- 1 : Fuel pump control relay
- 2 : Locking relay.
- 3 : Injection power circuit protection relay

REMOVAL - REFITTING




Release the connector (1) from its mounting and disconnect it.

Remove the TDC sensor mounting bolts (2) and remove the sensor.

When refitting:

Fit the sensor using shouldered bolts and washers. (Do not forget the earth strap (3)).


Replace the connector correctly and ensure it is correctly clipped.



NOTE : The engine flywheel has a 58 tooth target (60 minus 2)

The absolute pressure sensor is mounted on the windscreen wiper motor mounting.

REPLACEMENT




Disconnect the connector (1) and the vacuum pipe (2)

Release the pressure sensor (3) which is clipped onto the mounting.


When refitting, ensure the connector is correctly clipped into position.

REMOVAL - REFITTING



Disconnect the sensor wiring (connector 1).

Unscrew the sensor (2). Do not let it drop



When refitting:

Torque tighten the sensor to 3 daN.m.
Check the wiring is correctly positioned and the connector is correctly re clipped.


Note:

The wiring may not be spliced or soldered. If it is broken, replace the sensor.

ADVANCE RETARD DEVICE

Although the vehicle is not fitted with pinking sensor, the ignition advance may still be adjusted. If the engine is pinking a 3 degree retard of the advance setting may be made.

This correction is not applicable for the complete engine operating range, but only for a manifold pressure of above 850 millibars (close to full load). To make this correction, disconnect connector (1) and connect track n° 8 on the computer to earth.

Location**Procedure :**

To activate the correction (engine stopped) :

- Disconnect the connector (1).
- Turn the ignition on.
- Connect the XR25 and enter code D13.

Left hand bargraph on line 20 is illuminated.
The correction is active.

To de-activate the correction (engine stopped) :

- Reconnect connector (1).
- Turn the ignition on.
- Connect the XR25 and enter code D13.

Left hand bargraph on line 20 is extinguished.
The correction is de-activated.

In both cases, enter the diagnostics end code G13* before disconnecting the XR25.

Note:

Before activating the advance correction, check the pinking is not due to incorrect :

- fuel
- plugs
- inlet circuit (thermostatic element).
- engine cooling or fouling.

| Type | Engine | Bosch | NGK | Adjustment in (mm) ± 0,05 |
|-------|---------|----------|--------------|------------------------------|
| C 063 | C3G 700 | W9DC (1) | BP 5 ESZ (1) | 0,9 |

(1) Plug with seal: tightening torque 2,5 to 3 daN.m


ATTENTION : Use the correct type of plug specified; the thermal suffix is not the only factor in their selection.

Fault finding using the XR25

KEY

- 108 : Ignition coil
- 120 : Injection computer
- 147 : Absolute pressure sensor
- 149 : TDC sensor
- 169 : Canister bleed solenoid
- 193 : Injector.
- 218 : Fuel pump
- 222 : Throttle position potentiometer.
- 225 : Diagnostic socket.
- 236 : Fuel pump relay.
- 238 : Injection locking relay.
- 242 : Oxygen sensor.
- 244 : Coolant temperature sensor
- 272 : Air temperature sensor
- 597 : Engine fuse box.
- 649 : Idle speed adjustment stepping motor
- R224 : Earth connection - advance correction
adjustment
- MK : Electric earth - FLH pillar
- NF : Engine electronic earth.

OPERATIONAL WIRING DIAGRAM



MAGNETI - MARELLI NEW FAULT FINDING FICHE

11 N° 23 CARD IDENTIFICATION: READ ON DISPLAY → 5. InJ

| | | | |
|----|---------------------------------|------------------------------|--|
| 1 | COMPUTER | CODE PRESENT | |
| 2 | CONNECTION 1511 COMP → COIL *02 | ANTI-THEFT LOCK CIRCUIT | |
| 3 | INVERSE FLYWHEEL DATA | FLYWHEEL SIGNAL FAULT | |
| 4 | FUEL PUMP CIRCUIT RELAY | INJECTOR SHORT CIRCUIT | |
| 5 | IDLE REG MOTOR CIRCUIT | AIR TEMP SENSOR CIRCUIT | |
| 6 | | COOLANT TEMP SENSOR CIRCUIT | |
| 7 | | CANISTER CIRC *27 | |
| 8 | OXYGEN SENSOR SHORT CIRCUIT | PRESSURE SENSOR CIRCUIT | |
| 9 | ADAC CIRCUIT | VEHICLE SPEED SENSOR CIRCUIT | |
| 10 | THROTTLE VALVE POT CIRCUIT | PINKING SENSOR CIRCUIT | |

CODE D13 (S8)

INJECTION MAGNETI MARELLI

MEMORY DEL. **G 0 ****
END OF TEST **G 1 3 ***

ADDITIONAL CHECKS : # . .

| | | |
|----|---------------------|------|
| 01 | Pressure | mb |
| 02 | Coolant temp | °C |
| 03 | Air temp | °C |
| 04 | Computer feed | V |
| 05 | Oxygen sensor | V |
| 06 | Engine speed | rpm |
| 12 | RCO idle | % |
| 13 | Pinking signal | |
| 14 | Speed diff | rpm |
| 15 | Pinking corr. | d° |
| 16 | Atm pressure | mb |
| 17 | Throttle pot | |
| 18 | Veh speed | Km/h |
| 30 | Operating rich corr | |
| 31 | Idle rich corr | |
| 35 | Richness corr | |

COMMAND MODE : G . #

TESTS

| | |
|----|------------|
| 10 | Fuel pump |
| 14 | Idle reg |
| 16 | Canister |
| 21 | Warn light |

ADJUSTMENT CORRECTION

| | |
|----|---------------|
| 83 | Increase idle |
| 84 | Decrease idle |

70 PART No


| | | |
|----|---|-----------------------|
| 11 | PG ← THROTTLE POSITION → PL | |
| 12 | | |
| 13 | ANTI-THEFT active | Memory Fault *33 |
| 14 | Flywheel sensor signal Eng not running | |
| 15 | PUMP ACTIVE engine running | |
| 16 | IDLE REG active | CANISTER PURGE active |
| 17 | SELECTION | AIR COND FAULT |
| 18 | AIR CONDITIONING REQUEST | AUTHORISATION |
| 19 | | RICHNESS REG active |
| 20 | RETARD ADVANCE request | MEMORY XR 25 |

ANG

When fault finding on Magnéti-Marelli injection systems, use cassette N° 11, place the ISO selector on S8 and use the fault finding fiche shown above (N° 23).

The computer is identified by directly reading the part number of the component. This is done after entering D13, by entering code G 70*.

The part number is displayed on the central screen in three stages. Each stage is displayed for approximately two seconds and the whole display is repeated twice.



Erasing the memory (GO**)

Following operations on the injection system, the computer memory can be erased using code GO**.(ISO selector on position 58).

No other computer is affected by this operation.

Note:

When using the XR25, before turning the ignition off or disconnecting the diagnostic socket, enter code G 13* to leave the injection fault finding mode.

Note : The memory can only be erased when the ignition is on (The memory cannot be erased when the engine is running)

The various G..* modes have no effect on the vehicle.

ACCESS TO COMPUTER INFORMATION USING THE # KEY.


| # key | Tests carried out | Units |
|-------|--|-----------|
| 01 | Manifold pressure | Millibars |
| 02 | Coolant temperature | Degrees |
| 03 | Air temperature | Degrees |
| 04 | Feed voltage | Volts |
| 05 | Oxygen sensor voltage | Volts |
| 06 | Engine speed | Rpm |
| 12 | RCO Idle speed adjustment stepping motor | % |
| 14 | Engine speed offset | Rpm |
| 16 | Atmospheric pressure correction | Millibars |
| 17 | Throttle position potentiometer value | No units |
| 18 | Vehicle speed | Km/h |
| 30 | Average load and full load adaptive pressure | No units |
| 31 | Low load adaptive pressure | No units |
| 35 | Richness correction | No units |

Adaptive richness correction (#30 and 31)

These adaptive corrections are used to re-centre the richness correction (#35) to about 128, following diverse engine operation.

This optimises engine performance in the non-loop phase (oxygen sensor not operational).

Operating range







These corrections may only be made when the coolant temperature is equal to or above 75°C.













NOTE : These factors may only be analysed when one of these values is at the maximum or minimum threshold and when the engine is operating incorrectly. When the memory is erased, any corrections which may have been made previously are cancelled (#30 = #31 = 0).

| | Min. value | Max. value |
|-----|------------|------------|
| #30 | - 37 | 105 |
| #31 | - 14 | 30 |

BARGRAPH FUNCTIONS

- | | |
|--|---|
| <p> Bargraph normally illuminated, engine stopped and ignition on.</p> <p> Bargraph illuminated when component is operated (condition bargraph).</p> | <p> Bargraph which may illuminate if there is a fault : - fixed: fault present - flashing: temporary fault.</p> <p> Bargraph does not operate for this vehicle type</p> |
|--|---|

PRESENTATION OF VARIOUS BARGRAPHS:

| | | |
|---|---|--|
| 1 |   | <p>Bargraph illuminated :</p> <ul style="list-style-type: none"> - on LH side : incorrect computer or internal problem. - on RH side : shows XR25 is receiving and reading the signals from the computer |
| 2 |   | <p>Bargraph illuminated, shows a fault on the ignition coil - computer line ; the fault is stored (Diagnosis of CO, CC + CC -)</p> |
| 3 |   | <p>Bargraph illuminated :</p> <ul style="list-style-type: none"> - on LH side : shows steering wheel sensor connections are inverted - on RH side : shows cyclical fault (target fault) |
| 4 |   | <p>Bargraph illuminated :</p> <ul style="list-style-type: none"> - on LH side : CC + on fuel pump relay line, computer. The fault is stored. - on RH side : Injector short circuit. The fault is stored |
| 5 |   | <p>Bargraph illuminated :</p> <ul style="list-style-type: none"> - on LH side : short circuit idle speed adjustment stepping motor; the fault has been stored (diagnosis of CC + , CC - , CC coil). - on RH side : fault on air temperature sensor line ; air temperature takes default value of 33°C. <p>The fault is stored. (Diagnosis of CO, CC - or CC +)</p> |
| 6 |  | <p>Bargraph illuminated shows a fault on the coolant temperature sensor line. The default value 90 °C is used if there is a fault. The fault is stored (Diagnosis of CO, CC - or CC +)</p> |
| 7 |  | <p>Bargraph illuminated shows a fault on the canister bleed solenoid line. The fault is stored. (Diagnosis of CO, CC - or CC +)</p> |

CO : Open circuit
 CC + : short circuit to +
 CC - : short circuit to earth


PRESENTATION OF VARIOUS BARGRAPHS (cont)

| | | |
|----|--|---|
| 8 | | <p>Bargraph illuminated:</p> <ul style="list-style-type: none"> - on LH side : short circuit on oxygen sensor line. The sensor voltage (value under # 05) tends to 0 and the value of # 35 is 128. The fault is not stored. - on RH side : Presence of fault in absolute pressure sensor or its wiring. The manifold pressure value under # 01 takes a fixed value or a value assigned by mapping, depending on the throttle angle and the engine speed. The fault is not stored. |
| 9 | | Not used for this vehicle type |
| 10 | | Bargraph illuminated shows a fault in the throttle position potentiometer or its wiring. The default value under # 17 is 128 (or 64 for a CD or CC on the computer line (track 14)-potentiometer, engine stopped). The fault is stored. (Diagnosis of CO, CC + or CC -) |
| 11 | | <p>Bargraph illuminated :</p> <ul style="list-style-type: none"> - on LH side : throttle full load position info. (or full throttle) - on RH side : throttle no load position info. |
| 13 | | Bargraph illuminated shows a fault in the locking relay line, computer track 4. When this bargraph is illuminated, all other faults are masked. The fault is stored. |
| 14 | | Engine flywheel sensor signal. This bargraph should extinguish when the starter is activated |
| 15 | | Fuel pump active info |
| 16 | | <p>Bargraph illuminated :</p> <ul style="list-style-type: none"> - on LH side : Idle speed regulation stepping motor active info (only illuminated for no load). - on RH side : info which cannot be used for this vehicle |
| 17 | | Not used currently |
| 18 | | Not used currently |
| 19 | | Richness regulation active info (#05 and #35 are variable) |
| 20 | | <p>Bargraph illuminated :</p> <ul style="list-style-type: none"> - on RH side : memorised - on LH side : advance correction effective. |


Special notes for certain bargraphs

Bargraphs 2L, 7R, 13R have complementary tests: *02, ^ and *33. These tests are used to direct fault finding:


*02



: No fault on computer - ignition coil line




: Open circuit or short circuit to earth




: Short circuit to + battery


^27



: No fault with canister bleed solenoid or its wiring




: Open circuit or short circuit to earth detected




: Short circuit to + battery detected


*33



: No fault on locking relay computer track 4.









: Fault on locking relay computer track 4 line. All other faults which may have been stored before are masked.



: All stored faults erased (after entering GO**).


CHECKING CONFORMITY

Engine cold, ignition on :


| Functions to check | Line no. | Bargraph display | XR25 code | Central display - notes |
|--|------------------|--|-----------|--|
| Diagnostic signals received | | | D13 | 5. InJ |
| Computer correct | | | G70* | First 7 700 then 864 then 461 The part number is repeated twice |
| Interpretation of bargraphs normally illuminated | L1 L11 L14 |  | | Code present Recognition of no load position TDC signal missing (should extinguish when starter activated). |
| Absolute pressure sensor | L8 |  | # 01 | The value read should equal atmospheric pressure (between 900 and 1023 mb) |
| Coolant temperature sensor | L6 |  | # 02 | The value read should equal ambient temperature ± 5°C |
| Air temperature sensor | L5 |  | # 03 | The value read should equal ambient temperature. ± 5°C |
| Battery voltage | | | # 04 | The voltage should be between 11 V and 13 V (Without electrical consumers) |
| Throttle position potentiometer, no load | L11 |  | # 17 | The value read should be between 9 and 41 |
| Throttle position potentiometer, full load | L11 |  | # 17 | The value read should be between 168 and 235 |

CHECKING CONFORMITY

Engine warm at idle speed, after one operation of the engine cooling fan.

| Functions to check | Line no. | Bargraph display | XR25 code | Central display - notes |
|--|----------|--|--------------|--|
| Idle speed | | | # 06 | The idle speed should be 700 ± 50 rpm with no consumers connected |
| Idle speed regulation stepping motor | L16 |  | # 12 | The value read should be between 2 and 10 % with no consumers connected |
| Richness regulation active (at idle speed after the engine has stabilised at 2500 rpm for more than 3 minutes) | L19 | | # 05 # 35 | The value varies around 0,475 V. The value read should be between 93 and 163. |

XR25 CHECK ON THE INJECTION SYSTEM BEFORE ANY OPERATION IS CARRIED OUT



BARGRAPH 1 LH SIDE ILLUMINATED
Computer fault


Incorrect computer type. Replace the computer.

BARGRAPH 2 LH SIDE ILLUMINATED
Ignition coil circuit


Bargraph illuminates only when starter is activated : $t < 5s$

*02 on XR25 read :
CO = Open circuit or short circuit to earth on computer track 19.
CC = Short circuit to + 12 V on computer track 19.

OPEN CIRCUIT OR SHORT CIRCUIT TO EARTH



SHORT CIRCUIT TO + 12 VOLTS



NOTE : A short circuit to earth on track 19 blows the 25 A fuse (engine side)

BARGRAPH 3 LH SIDE ILLUMINATED
Steering wheel sensor circuit

Steering wheel sensor connections inverted. Check sensor connections. Vehicle will not start.


BARGRAPH 3 RH SIDE ILLUMINATED
Steering wheel sensor

Cyclical fault

- There is :
- a target fault (more serious for AT)
 - an air gap fault for the steering wheel sensor.
 - a micro cut in the steering wheel sensor circuit.

BARGRAPH 4 LH SIDE ILLUMINATED
Fuel pump relay


Short circuit to + 12 Volts on line 23 on computer.
Bargraph illuminated when starter activated..
Bargraph 2 LH side (ignition coil) is also illuminated
and * 02 = CO.



NOTE : An open circuit and a short circuit on computer line 23 prevent dialogue with the computer and functioning of the injection test

BARGRAPH 4 RH SIDE ILLUMINATED
Injector short circuit


When the starter is activated the bargraph illuminates for approximately 5 seconds



NOTE : An open circuit on 1 of the 2 injector wires or the connector being disconnected will not cause bargraph 4 RH side to illuminate.

BARGRAPH 5 LH SIDE ILLUMINATED
Idle speed regulation motor circuit


Short circuit to earth and short circuit to + on one of the 4 coil wires, (line 2,3, 20 or 21 on the computer)
 Coil short circuit (A and D or B and C)
 #12 = value fixed under acceleration



NOTE : An open circuit on one of the 4 motor wires or the connector being disconnected will not cause the bargraph top illuminate but the value of # 12 is fixed under acceleration.

BARGRAPH 5 RH SIDE ILLUMINATED
Air sensor


Open circuit on computer lines 16 and 31.
Short circuit to earth on computer line 31.
#03 = 33



NOTE : If bargraphs 6 RH side and 10 LH side are also illuminated there is an open circuit on the common earth wire between splice NA and computer line 16.

BARGRAPH 6 RH SIDE ILLUMINATED
Coolant sensor

Open circuit on computer lines 13 and 16
 Short circuit to earth on computer line 13
 #02 = 90



NOTE : If bargraphs 5 RH side and 10 LH side are also illuminated there is an open circuit on the common earth wire between splice NA and computer line 16.

BARGRAPH 7 RH SIDE ILLUMINATED
Canister circuit


Open circuit
Short circuit to earth
Short circuit to + 12 Volts

} on computer line 22

*27 on XR25 read :

CO.0 = open circuit or short circuit to earth


CC.1 = short circuit to + battery



BARGRAPH 8 LH SIDE ILLUMINATED
 Oxygen sensor

Short circuit for sensor between lines 12 and 29 on the computer
 Short circuit to earth on computer line 29

05 < 0,1 V
 # 35 = 128




Note : An open circuit on lines 12 and 29 or the oxygen sensor connector being disconnected will not cause bargraph 8 LH side to illuminate but # 05 and 35 take fixed values:

05 > 0,395
 # 35 = 128

BARGRAPH 8 RH SIDE ILLUMINATED
Absolute pressure sensor

Open circuit or short circuit to earth on computer lines 14 and 32.

01 = variable and dependent on throttle opening or fixed with a value which is not zero.




Note : An open circuit on line 16 or a short circuit on lines 16 and 32 will not cause bargraph 8 RH side to illuminate and # 01 is equal to 1020.

BARGRAPH 10 LH SIDE ILLUMINATED
Throttle potentiometer circuit

Open circuit on computer lines 14, 16 and 30.
 Short circuit to earth on computer lines 14 and 30
 Potentiometer short circuit between tracks 14 and 30

#17 = 128 or 64



NOTE : If bargraphs 5 RH side and 6 RH side are also illuminated there is an open circuit on the common earth wire between splice NA and computer line 16

BARGRAPH 11 RH SIDE
No load position

Condition bargraph normally illuminated for no load (PL)

Enter # 17 on the XR25 and check the throttle position potentiometer value for no load. $9 < \text{no load} < 41$

Erase the memory using G0** on the XR25.
Is PL present?

yes

Correct

no

Check if the throttle is against the
mechanical stop for no load
Is this correct?

no

Adjust the accelerator control

yes

Replace the throttle position
potentiometer. Does the fault
persist?

yes

Replace the computer

no

Correct

BARGRAPH 11 LH SIDE
Full load position

Bargraph illuminated for throttle opening $> 70^\circ$

Test to be carried out if bargraph is not illuminated for full load (PF)

Enter # 17 on the XR25 and check the throttle
position potentiometer value for full opening
 $168 < \text{full load} < 235$

Check if the throttle is against the
mechanical stop for full load. Is this correct?

no

Adjust the accelerator control

yes

Replace the throttle position
potentiometer. Does the fault
persist?

yes

Replace the computer

no

Correct

BARGRAPH 13 RH SIDE ILLUMINATED
Memory fault

*33 on XR25 read :

Bon : after GO**

on : when the bargraph is extinguished

off : when the bargraph is illuminated

This bargraph is normally illuminated after :

- disconnecting the 35 track connector
- cutting battery feed (= 5 min)
- cutting permanent computer feed before ignition (computer line 4 or 25A engine side fuse).

To extinguish this bargraph turn the ignition off (= 10 s), then turn the ignition back on or enter GO** on the XR25 to erase the memory; if the bargraph extinguishes you should read *33 = bon.
Does the bargraph extinguish?

yes → Correct

no

Check there are not micro-cuts in the permanent feed line (AVC) for the computer between track 4 on the computer and track 2 on the protection relay, also check the computer and relay connections and the 25A fuse contacts (engine side). Repair if necessary.
Does the bargraph remain illuminated?


no → Correct

yes

Replace the computer

BARGRAPH 14 LH SIDE ILLUMINATED
Steering wheel sensor circuit

The bargraph does not extinguish when the starter is activated.



Note : This bargraph may extinguish when the ignition is on after G0**, in this case re-enter D13 or turn the ignition off and on again then enter D13.

CUSTOMER COMPLAINTS

Starting faults

- Does not start
- Starts but stalls
- Starting takes too long

Chart 1A - 1B - 1C
Chart 2
Chart 3

Idle speed faults

- Too high
- Engine speed unstable
- Jerky operation

Chart 4
Chart 5
Chart 6

Behaviour while driving

- Lack of performance
- Misfires and jerky operation

Chart 7
Chart 8

Smoke - pollution

- Black smoke
- Lack of conformity to anti-pollution regulations
- CO and or HC too high

Chart 9
Chart 10

Increased fuel consumption

Chart 11


Engine noise

- Pinking

Chart 12


Starting faults

Chart 1A : Does not start




* : An open circuit or a short circuit to earth on computer line 23 prevents dialogue between the computer and the XR25, and prevents engine testing.
A short circuit to +12 Volts on computer line 23 illuminates bargraphs 4 LH side and 2 LH side when the starter is activated.

Starting faults



Starting faults


Chart 1C : Does not start



(*) Bargraph 4 RH side will not illuminate if there is an open circuit in the injector circuit.

Starting faults

Chart 2 : The engine starts but stalls




(1) Bargraph 5 LH side will not illuminate if there is an open circuit on one of the idle speed regulation motor wires or if the idle speed regulation motor connector is disconnected

(2) Bargraph 8 RH side will not illuminate for :

- CO on track 16
- CC between tracks 14 and 32.


Starting faults

Chart 3: Starting takes too long



Idle speed faults


Chart 4 : Idle speed too high



(*) Bargraph 5 LH side will not illuminate if there is an open circuit on one of the 4 idle speed regulation motor wires or if the idle speed regulation motor connector is disconnected.

Idle speed faults

Chart 5 : Engine speed unstable




(*) Bargraph B RH side will not illuminate for :

- CO on track 16
- CC between tracks 14 and 32.


Idle speed faults

Chart 6 : Jerky operation




Behaviour while driving

Chart 7 : Lack of performance



Behaviour while driving

Chart 8 : Misfires and jerky operation




(*) Bargraph 8 RH side will not illuminate for :

- CO on track 16
- CC between tracks 14 and 32.


Smoke - Pollution

Chart 9 : Black smoke




Smoke - pollution

Chart 10 : Lack of conformity to anti-pollution regulations
CO and / or HC too high
CO > 0,3 % - HC > 100ppm



Note : An open circuit on oxygen sensor lines 12 and 29 will not illuminate bargraph 8 LH side but
05 and 35 take fixed values :
05 > 0,395
35 = 128.


Chart 11 : Increased fuel consumption



(*) Bargraph 8 RH side will not illuminate for :

- CO on track 16
- CC between tracks 14 and 32.

Chart 12 : Noise - pinking



(*) Bargraph 8 RH side will not illuminate for :

- CO on track 16
- CC between tracks 14 and 32.

QUANTITY AND QUALITY OF ANTI-FREEZE

| Engine | Quantity (in litres) | Quality | Notes |
|--------|----------------------|---|--|
| C3G | 5,5 | GLACEOL AL (type C) use coolant only | Protection down to - 23 °C for temperate and cold countries Protection down to - 40 °C for extreme cold countries |

THERMOSTAT

| Engine type | Starts opening (in °C) | Fully open (in °C) | Travel (in mm) |
|-------------|------------------------|--------------------|----------------|
| C3G | 89 | 101 | 7,5 |

ANTI-FREEZE CONCENTRATION

Density gauge
Supplier:
- FACOM
6 et 8, rue Gustave Eiffel-BP 99
91423 MORANGIS

DENSITY GAUGE 778A (1)

Take up some coolant so that the liquid covers the base of the thermometer and allows the density gauge to float freely.

Check that the density gauge:


Is not jammed against the upper lip of the tube (too much liquid).

Is not stuck against the side of the tube - if necessary, tap lightly to free the gauge

Read:

- the temperature of the liquid,
- the density of the liquid.

Refer to the correction table below to determine the effective degree of protection of the coolant.



| | | DENSITY READING | | | | | | | DEGREES CENTIGRADE BELOW 0° |
|------------------------|----|---------------------------------|----|----|----|----|----|----|--------------------------------------|
| | | 3 | 5 | 10 | 15 | 20 | 30 | 40 | |
| THERMOMETER READING | 10 | 0 | 0 | 5 | 8 | 11 | 14 | 18 | |
| | 20 | 1 | 2 | 6 | 10 | 14 | 18 | 24 | |
| | 30 | 2 | 3 | 8 | 12 | 17 | 24 | 33 | |
| | 40 | 3 | 5 | 10 | 15 | 20 | 30 | 40 | |
| | 50 | 4 | 7 | 12 | 18 | 24 | 35 | | |
| | 60 | 6 | 9 | 15 | 22 | 28 | 40 | | |
| | 70 | 8 | 12 | 18 | 25 | 32 | | | |
| | 80 | 10 | 14 | 22 | 32 | 37 | | | |
| | | CORRECTED PROTECTION IN DEGREES | | | | | | | |

EXAMPLE { Thermometer reading : 60 } PROTECTION
 { Density gauge reading : 10 } to MINUS 15°C

Refractory gauge
Supplier:
- CEPAC
Contact your After Sales Head Office for further information.

Take a sample of liquid from the expansion bottle.
Read off the protection value on the refraction gauge.

Hot, temperate cold countries:
Protection - 23 °C (35 % anti-freeze mixture).
Extreme cold countries :
Protection - 40 ° C (50 % anti-freeze mixture).

Protection is reduced when the concentration exceeds 60 % anti-freeze.
The degrees of protection in the table are valid for a coolant temperature of 40 °C.

Use the tables below
For vehicles with 6 litres coolant capacity, for a protection read at - 15 °C.

To exceed protection to - 23 °C, replace 0,7 litre of coolant from the circuit with 0,7 litre of pure anti-freeze.
To exceed protection to - 40 °C, replace 1,9 litre of coolant from the circuit with 1,9 litre of pure anti-freeze.

PURE ANTI-FREEZE TO BE ADDED

| | | - 23 °C Hot, temperate and cold countries | | | | |
|---|---|--|-----|-----|-----|-----|
| Protection at 40 °C (coolant temperature) | | Circuit capacity (litres) | | | | |
| | | 5 | 6 | 7 | 8 | 9 |
| - 5 °C | * | 1,3 | 1,6 | 1,8 | 2,1 | 2,4 |
| - 10 °C | * | 1,0 | 1,1 | 1,3 | 1,5 | 1,7 |
| - 15 °C | * | 0,6 | 0,7 | 0,9 | 1,0 | 1,1 |
| - 20 °C | * | 0,2 | 0,2 | 0,2 | 0,3 | 0,3 |

| | | - 40 °C Extreme cold countries | | | | |
|---|---|-----------------------------------|-----|-----|-----|-----|
| Protection at 40 °C (coolant temperature) | | Circuit capacity (litres) | | | | |
| | | 5 | 6 | 7 | 8 | 9 |
| - 5 °C | * | 2,2 | 2,6 | 3,1 | 3,5 | 3,6 |
| - 10 °C | * | 1,9 | 2,3 | 2,7 | 3,0 | 3,4 |
| - 15 °C | * | 1,6 | 1,9 | 2,2 | 2,6 | 3,0 |
| - 20 °C | * | 1,3 | 1,6 | 1,8 | 2,0 | 2,3 |
| - 25 °C | * | 1,0 | 1,2 | 1,4 | 1,7 | 1,9 |
| - 30 °C | * | 0,9 | 1,0 | 1,2 | 1,4 | 1,5 |
| - 35 °C | * | 0,5 | 0,5 | 0,6 | 0,7 | 0,8 |

* = Volume of liquid to be replaced by Glaceol AL TYPE C anti-freeze in order to obtain protection down to -40 °C

ALUMINIUM RADIATORS

Certain vehicles are fitted with aluminium section radiators.

Rinsing

Never rinse these components or the cooling circuit with caustic soda or alkaline products (light alloy sections may corrode and cause leaks).

Storage

These radiators may be stored with no special precautions for a maximum of 48 hours after removal.

After this period the brazing flux particles which enter the radiator during manufacture and the dichlorate chemicals from the coolant previously in the radiator cause oxidation of the aluminium radiator components when in contact with the air, causing leaks

If a radiator is to be removed for more than 48 hours:

- **RINSE WITH COPIOUS AMOUNTS OF WATER, BLOW OUT** with compressed air then **PLUG** all openings, or
- **Keep the radiator full of coolant** if possible.

Anti-freeze

Aluminium radiators require special anti-freeze.

AL type C anti-freeze which is marketed by the Renault Network meets the requirements set by our Design Office for:

- neutral reactivity with various cast aluminium components,
- alkalinity specifications adapted for light alloys,
- special additives which give efficient protection against acidic combustion products both for Diesel and Petrol engines
- concentration ensuring protection and good operation at all temperatures

There is no heater matrix valve

The coolant is continuously circulated in the heater matrix, contributing to engine cooling.

FILLING

Check the drain plug/s are tight

Open the bleed screw/s.

Fill the circuit through the expansion bottle .

Unclip the hose from the top of the computer and position it below the expansion bottle.

Close the bleed screw/s as soon as liquid runs out in a continuous jet.

Start the engine (1 500 rpm)

Adjust the overflow level for 4 minutes approximately.

Close the bottle

BLEEDING

Let the engine run for 10 minutes at 1 500 rpm, until the engine cooling fan operates. (time required for automatic de-gassing).

Check the coolant level is near the "Max" mark.

NEVER OPEN THE BLEED SCREW/S WHEN THE ENGINE IS RUNNING..

REPLACE THE EXPANSION BOTTLE CAP WHEN THE ENGINE IS WARM.

SPECIAL TOOLING REQUIRED

| | | |
|------|--------|---|
| M.S. | 554-05 | Kit for testing cooling circuit sealing |
| M.S. | 554-01 | Adapter for M.S. 554-05 |
| M.S. | 554-06 | Adapter for M.S. 554-05 |

1 - Testing the sealing of the circuit

Replace the expansion bottle valve with adapter M.S. 554-01.

Connect this to tool M.S. 554-05.

Let the engine warm up then stop it.

Pump to put the circuit under pressure.

Stop pumping at 0,1 bar less than the valve is rated.

The pressure should not drop, otherwise look for the leak.

Slowly unscrew the union of tool M.S. 554-05 to decompress the cooling circuit, then remove tool M.S. 554-01 and refit the expansion bottle valve with a new seal

2 - Checking the rating of the valve.

If liquid passes through the expansion bottle valve, the valve must be replaced.


On pump M.S. 554-05 fit tool

M.S. 554-06 and fit the assembly on the valve to be checked.


Increase the pressure which should stabilise at the valve rating pressure with a test tolerance of $\pm 0,1$ bar.

Valve rating :


Brown colour plastic valve 1,2 bar.



82 999-1







82 999-1




96 312 R

- 1 Engine
- 2 Radiator
- 3 Cold bottle
- 4 Heater matrix
- 11 Throttle body

-  Water pump
-  Thermostat
-  Bleed screws
-  Temperature switch

IMPORTANT : Whenever work is carried out on the fuel tank or fuel supply circuit, never smoke and keep all heat sources away from the working area


DRAINING THE FUEL TANK



Tilt the rear bench seat forward

Lift the carpet and remove the plug.

Disconnect the fuel supply pipes (1) and return pipes (2) using a special set of pliers Mot. 1 265 (see diagram)




Fit a hose onto the fuel pump outlet (1) (hose must be long enough to fit into a container)

Disconnect the fuel pump relay (3).

To operate the pump, shunt between tracks (3) and (5).

When the fuel is being pumped out intermittently, replace the relay having removed the shunt.



NOTE : up to 11 litres of fuel may remain in the fuel tank after this operation (this is due to the shape of the fuel tank).

REMOVING - REFITTING THE FUEL TANK


Drain the fuel tank.

Disconnect the battery

Disconnect the connector from the pump - gauge assembly and the fuel return pipe.

Remove:

- the rear right hand wheel,
- the rear bumper,
- the heat shield (4),
- the silencer.



Disconnect the pipe (5) from the fuel filter using pliers **Mot. 1 265**.

Loosen the handbrake adjustment control to release the cables.

Unhook the brake pipes at (A)

Remove the filler neck mounting bolt

Position a jack under the fuel tank.

Remove the five fuel tank mounting bolts (6)

Lower the fuel tank by about 10 centimetres then tilt to the right to remove the brake pipes.

Disconnect the fuel vapour recirculation pipe using pliers **Mot. 1 265** (union by the filler neck), and remove this pipe from the tank.


Lower the fuel tank completely.

When refitting ensure :

- the fuel vapour recirculation pipe and the fuel supply pipes are refitted onto the fuel tank correctly
- the pump - gauge connector is not crushed.


Adjust the handbrake

FUEL TANK ASSEMBLY



96 188 R

- 1 Pump - gauge assembly
- 2 Fuel filter
- 3 Fuel supply pipe
- 4 Filler neck - tank connection
- 5 fuel vapour recirculation pipes

**BALL JOINT CONNECTION AND SEALING WITH
"METEX" RING**

- 1 Exhaust manifold
- 2 "Metex" ring
- 3 Studs
- 4 Exhaust downpipe

Studs (3) on the exhaust downpipe are fitted with stops to determine the tension of the springs. Tighten until they reach the stop.

A "Metex" friction ring (2) is used to seal the joint.

IMPORTANT :

The sealing between the manifold gasket surface and the catalytic converter must be perfect.


When replacing the catalytic converter, check the condition of the "Metex" ring (2) and replace it if necessary.

During removal and refitting, the catalytic converter should not be subjected to mechanical shocks, which, if repeated, could damage the converter.

REMOVAL - REFITTING

Remove

- the rear bumper (it is held in position by four bolts and two nuts),
- the heat shield (1) under the fuel tank,



- the collar connecting the catalytic converter to the silencer,
- the various rubber mountings ensuring the silencer is mounted securely to the underside of the body.

Remove the silencer towards the rear of the vehicle.

When refitting the silencer refit the various components in the reverse order to when they were removed

Check the heat shield is correctly refitted.

NOISE IN THE EXHAUST LINE

The vehicle must be tested to determine the location of the noise (if necessary with the customer). The noise should then be reproduced when stationary. To do this, accelerate sharply to cover a wide range of engine speeds and resonances.

Having reproduced the fault :

- ensure the exhaust line is not touching the body,
- check the alignment, conformity and condition of the exhaust assembly,
- try to eliminate the noise noted by tightening the exhaust line section or heat shields at fault.

If the noise is coming from the catalytic converter, remove it and test as follows:

- visual examination inside the envelope (internal section melted),
- aural examination after shaking the component (internal section broken or foreign body inside).

If the internal section has melted the cause must be determined (see chapter 14 : test to be carried out before anti-pollution tests) and check that catalytic converter particles have not blocked the exhaust system further down.

Only if one of the faults mentioned above is found, replace the converter.

IMPORTANT NOTE : never park or run the engine in an area where combustible material could touch the exhaust line which can become extremely hot.

These materials may ignite under certain conditions